City of Westminster's Wakefield Valley Water System

This brochure explains the quality of drinking water provided by Wakefield Valley Water System. Included is a listing of results from water quality tests as well as an explanation of where our water comes from and tips on how to interpret the data. We're proud to share our results with you. Please read them carefully.

We are proud to report that the water provided by Wakefield Valley Water System meets or exceeds established water quality standards.

Overview

In 2000, Wakefield Valley Water System brought on line Diatomateous Earth (DE) filtration to ensure drinking water quality.

Water Source

Wakefield Valley Water System is supplied by groundwater pumped from 2 wells in Wakefield Valley in central, western Carroll County. A source water assessment is available from the Westminster Branch of the Carroll County Public Library.

Important Health Information

Drinking water, including bottled water, may reasonably be expected to contain at least small amounts of some contaminants. The presence of contaminants does not necessarily indicate that water poses a health risk. More information about contaminants and potential health effects can be obtained by calling the Environmental Protection Agency's Safe Drinking Water Hotline (800-426-4791).

The sources of drinking water (both tap water and bottled water) include rivers, lakes, streams, ponds, reservoirs, springs, and wells. As water travels over the surface of the land or through the ground, it dissolves naturally-occurring minerals and, in some cases, radioactive material, and can pick up substances resulting from the presence of animals or from human activity. Contaminants that may be present in source water include:

- (A) Microbial contaminants, such as viruses and bacteria, which may come from sewage treatment plants, septic systems, agricultural livestock operations, and wildlife.
- (B) Inorganic contaminants, such as salts and metals, which can be naturally-occurring or result from urban stormwater runoff, industrial or domestic wastewater discharges, oil and gas production, mining, or farming.
- (C) Pesticides and herbicides, which may come from a variety of sources such as agriculture, urban stormwater runoff, and residential uses.
- (D) Organic chemical contaminants, including synthetic and volatile organic chemicals, which are by-products of industrial processes and petroleum production, and can also come from gas stations, urban stormwater runoff, and septic systems.
- (E) Radioactive contaminants, which can be naturally-occurring or be the result of oil and gas production and mining activities.

In order to ensure that tap water is safe to drink, EPA prescribes regulations which limit the amount of certain contaminants in water provided by public water systems. FDA regulations establish limits for contaminants in bottled water which must provide the same protection for public health.

Some people may be more vulnerable to contaminants in drinking water than the general population. Immunocompromised persons such as persons with cancer undergoing chemotherapy, persons who have undergone organ transplants, people with HIV/AIDS or other immune

system disorders, some elderly, and infants can be particularly at risk from infections. These people should seek advice about drinking water from their health care providers. EPA/CDC guidelines on appropriate means to lessen the risk of infection by *Cryptosporidium* and other microbial contaminants are available from the Safe Drinking Water Hotline (800-426-4791).

What About Radon?

Wakefield Valley Water System tested for radon in your water and found it to be present at a level of 40 picocuries per liter.

Radon is found throughout the U.S. It is a radioactive gas that you can't see, taste, or smell. Radon can move up through the ground and into a home through cracks and holes in the foundation. Radon can also get into indoor air when released from tap water from showering, washing dishes, and other household activities. Compared to radon entering the home through soil, radon entering the home through tap water will in most cases be a small source of radon in indoor air.

If you are concerned about radon in your home and would like additional information on how to test your home, contact the EPA's Radon Hotline (800-SOS-RADON).

How to Read the Water Quality Table

The results of tests performed in 2016 or the most recent testing available are presented in the table. Terms used in the Water Quality Table and in other parts of this report are defined here.

Maximum Contaminant Level or MCL: The highest level of a contaminant that is allowed in drinking water. MCLs are set as close to the MCLGs as feasible using the best available treatment technology.

Maximum Contaminant Level Goal or MCLG:

The level of a contaminant in drinking water below which there is no known or expected risk to health. MCLGs allow for a margin of safety.

Detected Level: The highest level detected of a contaminant for comparison against the acceptance levels for each parameter. These levels could be the highest single measurement, or an average of values depending on the contaminant.

Action Level: The concentration of a contaminant which, if exceeded, triggers treatment or other requirements which a water system must follow.

Range: The lowest to the highest values for all samples tested for each contaminant. If only one sample is tested, or no range is required for this report, then no range is listed for that contaminant in the table.

Treatment Technique (TT): A required process intended to reduce the level of a contaminant in drinking water.

Please call Bret Grossnickle at 410-848-7040 for information about participation in our community's decisions affecting drinking water.

Member of:

American Water Works Association (AWWA)

PWSID #0060017

Wakefield Valley Water System Water Quality Table

Inorganic Contaminants	Date Tested	Units	MCLG	MCL	Highest Level Detected	Range	Major Sources
Fluoride	2016	ppm	4	4	0.6	0.6 – 0.6	Erosion of natural deposits; Water additive which promotes strong teeth; Discharge from fertilizer and aluminum factories
Nitrate	2016	ppm	10	10	3.93		Runoff from fertilizer use; Leaching from septic tanks, sewage; Erosion of natural deposits
Barium	2015	ppm	2	2	.012	0.012 - 0.012	Discharge of drilling wastes; Discharge from metal refineries; Erosion of natural deposits
Copper	2015	ppm	1.3	AL=1.3	90% level = 0.66		Corrosion of household plumbing systems; Erosion of natural deposits; Leaching from wood preservatives
Lead	2015	ppb	0	AL=15	90% level = 6.2		Corrosion of household plumbing systems; Erosion of natural deposits
Chromium	2015	ppb	100	100		2 - 2	Discharge from steel and pulp mills; Erosion of natural deposits

Microbiological Contaminants	Date Tested	Units	Limit (Treatment Technique)		Level Detected	Major Sources
Turbidity	2016	NTU	5	TT	0.28	Soil runoff
Lowest monthly % meeting limit	2016	NTU	1		100 %	

Volatile Organic Contaminants	Date Tested	Units	MCLG	MCL	Average Detected Level	Range	Major Sources
Chlorine	2016	ppm	MRDLG = 4	MRDL = 4	1.2	0 – 1.2	Water additive used to control microbes
TTHM	2016	ppb	na	80	37	16.7 – 59.3	By-product of drinking water chlorination
HAA5	2016	ppb	na	60	2	0 – 9.1	By-product of drinking water chlorination
Synthetic Organic Contaminants	Date Tested	Units	MCLG	MCL	Highest Level Detected	Range	Major Sources
Di (2-Ethylhexyl) Phthalate	2014	ppb	0	200	1.05	1.05 – 1.05	Discharge from rubber and chemical factories

Key To Table

AL = Action Level

MCL = Maximum Contaminant Level MCLG = Maximum Contaminant Level

Goal

NTU = Nephelometric Turbidity Units ppm = parts per million, or milligrams per liter (mg/L)

ppb = parts per billion, or micrograms per liter (ug/L)

TT = Treatment Technique

na = not applicable

This report was provided with the technical assistance of Consumer Confidence Services,

a division of Environmental Health Laboratories.

For more information, call Bret Grossnickle with the City of Westminster at 410-848-7040

If present, elevated levels of lead can cause serious health problems, especially for pregnant women and young children. Lead in drinking water is primarily from materials and components associated with service lines and home plumbing. The City of Westminster is responsible for providing high quality drinking water, but cannot control the variety of materials used in plumbing components. When your water has been sitting for several hours, you can minimize the potential for lead exposure by flushing your tap for 30 seconds to 2 minutes before using water for drinking or cooking. If you are concerned about lead in your water, you may wish to have your water tested. Information on lead in drinking water, testing methods, and steps you can take to minimize exposure is available from the Safe Drinking Water Hotline or at http://www.epa.gov/safewater/lead